INTEGRA METERING

AMTRON® S3 / AMTRON® S3+ / AMTRON® S3U

Compact Heat Meter
Compact Heat/Cooling Meter
Compact Cooling Meter

Installation Guide and User Manual

DE-16-MI004-PTB025 (MID heat)
DE-16-M-PTB-0097 (national German cooling)
CH-T2-18768-00 (national Swiss cooling)



Legal notice

Document release index

Version	Date	Modification(s)
01	20.09.2021	First version
02	18.02.2026	Restructure of content & addition of chapter 13. Operating instructions communication interfaces

Original instructions

Publisher
INTEGRA Metering AG
Ringstrasse 75
CH-4106 Therwil
Switzerland

Phone: +41 61 725 11 22
info@integra-metering.com
www.integra-metering.com

Reproduction of these instructions or parts of them in whatever form is not permitted without express written permission from the publisher.

The figures and information in these instructions are subject to technical changes that become necessary to improve the product.

Content

1. Application and Function 5
2. Contents of the Package 5
3. General Information 5
3.1 Pictograms installation point 6
3.2 Pictograms type of meter (on type identification label) 6
4. Mounting the Flow Sensor 6
4.1 Mounting of AMTRON® S3 / AMTRON® S3+ / AMTRON® S3U (measuring tube) 6
4.2 Installation of AMTRON® S3 / AMTRON® S3+ in a fix installed single pipe connection piece 7
5. Detachable Calculator 8
6. Mounting the Temperature Sensors 8
7. Start of Operation 9
8. Display 9
8.1 Parametrizing loop 12
8.2 Detection of flow 13
9. Application Conditions 13
10. Interfaces and Options 13
10.1 Optical (infrared) interface 13
10.2 Retrofitting with an additional communication interface (optional) 14
10.3 Exchanging the Battery 15
10.4 Mounting a power pack 15
11. Information Messages 17
11.1 Message description 18
12. Manufacturer & contacts 18
13. Operating Instructions Communication Interfaces S3(C) 19
13.1 Interfaces and Options 19
13.2. M-Bus (optional) 19
13.2.1. Relevant norms / standards / literature M-Bus 19
13.2.2 Additional technical specifications 20
13.3 Modbus RTU (optional) 20
13.3.1 Technical data Modbus 20
13.3.2 Default factory settings 20
13.4. Wireless Interfaces 20
13.4.1. Radio interface wireless M-Bus EN 13757-3, -4 (optional) 21
13.4.2 LoRaWAN interface 23
13.4.3 Three additional pulse inputs (optional; only in conjunction with M-Bus or radio) 24
13.4.4 One potential-free pulse output (optional) 26
13.4.5 Two potential-free pulse outputs (optional) 28
13.4.6 Pin assignments 4-wire cable 28
13.5 Retrofitting with an Additional Communication Interface 28

13.5.1 Retrofitting S3 with an additional communication interface (optional)..... 28
13.6 Display in the Module Loop (Optional)..... 31

1. Application and Function

This AMTRON® S3 / AMTRON® S3+ / AMTRON® S3U is designed for the measurement of the consumed energy in a closed heating, cooling or heating / cooling system.

2. Contents of the Package

- Heat meter or heat/cooling meter, consisting of a calculator, a flow sensor and two temperature sensors, all permanently connected to each other
- Installation kit (depending on type)
- Installation and Operating Instructions
- Operating Instructions „Communication Interfaces S3(C)“ (with meters with an optional interface)
- Declaration of Conformity

3. General Information

- Valid standards for the application of heat meters: EN 1434, parts 1 – 6; the Measuring Instruments Directive 2014/32/EU, Annexes I and MI-004; and the relevant national verification regulations.
- For the selection, installation, commissioning, monitoring and maintenance of the instrument observe the standard EN 1434 part 6, as well as the verification regulations PTB TR K8 + K9 for Germany (and any relevant national verification regulations in other countries).
- **For combined heat/cooling meters the cooling register has no verification. National regulations for the consumption measurement of cooling must be observed.**
- The technical regulations for electrical installations must be observed.
- This product fulfils the requirements of the European Council Directive on Electromagnetic Compatibility (EMC Directive) 2014/30/EU.
- The identification plate of the instrument and the seals must not be removed or damaged – otherwise the guarantee and the approved application of the instrument are no longer valid!
- To achieve measurement stability of the meter it is necessary that the water quality meet the requirements of the AGFW-recommendation FW-510 and the document VDI (Association of German Engineers) VDI 2035.
- The heat meter left the factory in conformance with all applicable safety regulations. All maintenance and repair work is to be carried out only by qualified and authorized technical personnel.
- **Instruments with activated radio function are not allowed on air freight.**
- The correct installation point in the system must be chosen: inlet or outlet flow (see item 3.1 'Pictograms installation point').
- The temperature sensor cables and the cable between the calculator and flow sensor must not be kinked, rolled up, lengthened or shortened.
- To clean the heat meter (only if necessary) use a slightly moist cloth.
- To protect against damage and dirt the heat meter should only be removed from the packaging directly before installation.
- If more than one heat meter is installed in one unit, care must be taken to ensure that all the meters have the same installation conditions.
- All specifications and instructions listed on the data sheet and in the Application Notes must be adhered to.
  Further information can be obtained at **www.integra-metering.com**
- The heat meter has a lithium-metal-battery. Do not open the batteries, do not bring the batteries into contact with water or expose them to temperatures above 80 °C. Do not charge them or short-circuit them.



- Instruments which have been replaced or exchanged must be disposed of according to relevant environmental regulations.

- The display is deactivated and can be activated for two minutes by pushing the button.
- **Unit of energy and installation point (outlet flow / inlet flow) can be set on location, only once, before start of operation by pushing the button or alternatively using the „Device Monitor“ software.**
- **Type and concentration of glycol in the medium of those mechanical meter types designed to be used with glycol can be set on location at any time using the „Device Monitor“ software (see item 8.1 for details).**

3.1 Pictograms installation point

On the right in the meter display in all information loops you will find one of the following two pictograms. The pictogram indicates in which pipe the meter is to be mounted.

	Installation in outlet flow
	Installation in inlet flow

3.2 Pictograms type of meter (on type identification label)


	Heat meter
	Cooling meter

4. Mounting the Flow Sensor

4.1 Mounting of AMTRON® S3 / AMTRON® S3+ / AMTRON® S3U (measuring tube)

- Flush the pipes professionally, taking care not to damage any system components. Then close all the shut-off valves.
- Open the nearest draining valve for pressure release.
- Drain the closed-off pipe section.
- Loosen the coupling rings and remove the old heat meter.
- Remove all old gaskets and clean the sealing surfaces. Insert new gaskets.
- Position the flow sensor correctly, taking into account the direction of flow (arrow on the side of the flow sensor)!
- Tighten the coupling rings.
- Rotate the calculator to the best position for read-out, or detach it and mount it nearby.

Note concerning **AMTRON® S3U**: For the mounting in a heating system with a small quantity of air in the medium we recommend to overturn the meter through 90°.




4.2 Installation of AMTRON® S3 / AMTRON® S3+ in a fix installed single pipe connection piece


The multi-jet flow sensor type MSH-IST has a 2“ connection as described in EN ISO 4064-4 / EN 14154-2 (IST; interface for Ista heat meters) and must be installed without an adapter.

Mounting the flow sensor type MSH-IST in a single pipe connection piece

- Flush the pipes professionally, taking care not to damage any system components. Then close all the shut-off valves. Open the nearest draining valve for pressure release.
- Drain the closed-off pipe section.
- Take into account the direction of flow (check the connection piece)!
- Remove the overflow flange or the old heat meter from the connection piece using a wrench.
- Remove all old gaskets. Check sealing surfaces and threads for imperfections or dirt. If necessary, debur or clean with a suitable cleaning liquid.
- Place the new profile gasket into the connection piece with the flat surface facing up.
- Lubricate the external thread of the flow sensor with a thin layer of food safe silicon grease.
- Check that the O-ring on the outlet of the flow sensor is in the correct position.
- Screw in the heat meter tightly by hand and then tighten additionally with a suitable wrench to the mechanical end stop (metal-to-metal).
- Rotate the calculator to the best position for read-out or detach it and mount it nearby.



5. Detachable Calculator



We also provide meters with detachable calculators, in order to simplify mounting in narrow installation spaces. To release the calculator pull it carefully up off the flow sensor.

For mounting the calculator on the wall, a wall support is latched onto the adapter of the flow sensor (between calculator and flow sensor). Remove the calculator. Hold the adapter of the flow sensor and rotate the wall mounting support anticlockwise until you can release it. Then attach the wall support at the desired place **with the flat surface towards the wall.**

We always recommend detaching the calculator from the flow sensor.


However, it is important to note that the calculator must be detached for the following versions:

- **Cooling and heat/cooling meters**
- **high temperature heat meter versions AMTRON® S3U (temperature range up to 130 °C)**
- **high temperature heat/cooling meter versions AMTRON® S3U (temperature range up to 120 °C).**

6. Mounting the Temperature Sensors

When installing the temperature sensors in existing immersion sleeves, the immersion sleeve must be determined and marked. The installer is required by law to provide unmarked immersion sleeves with a clear label. Use the enclosed label for this purpose.


Note on installation of symmetrical temperature sensors:
When mounting two external temperature sensors (symmetrical), make sure that the (right) temperature sensor with the following drawing is installed in the same heating train as the flow sensor:



Push the temperature sensor into the immersion sleeve as far as it will go. The inner diameters of the immersion sleeve and the temperature sensor must match [5.0; 5.2; 6.0 mm].

6.1 Direct mounting (ball valve and T-piece)

- Remove the blind plug / old temperature sensor and gasket / old O-ring. Clean connection surfaces.
- **Slide the O-ring off the temperature sensor and insert it to the bottom of the threaded opening of the ball valve or the T-piece.**
- Hold the temperature sensor at the screw only and insert it into the ball valve or the T-piece and screw tightly.
- **In doing so the plastic clip is locked in the first crimp (viewed from the top of the protective sheath) and must not be moved.**



7. Start of Operation

- Slowly open the shut-off valves.
- Check that there are no leaks.

Check the following points:


- Are all shut-off valves open?
- Is the meter of the right size?
- Is the heating (heating/cooling) system clear (dirt filters not clogged)?
- Is the temperature sensor installed in the flow sensor correctly sealed to the flow sensor?
- Does the directional arrow on the connection piece / flow sensor match the actual direction of flow?
- Is a flow volume displayed?
- Is a plausible temperature difference displayed?


When the meter is functioning properly, attach the seals to the exterior temperature sensors and the flow sensor (required to protect against manipulation).


8. Display


The calculator has a liquid crystal display with 8 digits and special characters. The values that can be shown are divided into five display loops. All data is retrieved using the push-button next to the display.
At the start you are automatically in the main loop (1st level).
By pressing the push-button longer than 4 seconds you change to the next display loop. Keep the push-button pressed until you reach the desired information loop.
By pressing the push-button briefly each time you can scan all the information within a loop. After 2 minutes of non-use of the push-button, the display will automatically be deactivated.

Level 1 / Main Loop:


<table>
<tr>
<td>


1) Total heat energy since start of operation (standard display); alternating display: cooling energy (for heat/cooling meter); when negative flow; information message (if an error was detected)</td>
<td>


2) Segment test on / off (all segments triggered simultaneously)</td>
<td>


3) Last reading date alternating with heat energy (cooling energy), volume, value tariff register 1, value tariff register 2 at last reading date.[1)] (If the meter has 3 pulse inputs, their values follow.[2)])</td>
<td>


4) Total flow volume in m³</td>
</tr>
<tr>
<td>


5) Current date alternating with time</td>
<td>

6) Information message (alternating binary and hexadecimal display)</td>
<td>

7) Tariff register 1: value alternating with tariff register no. and criteria</td>
<td>

8) Tariff register 2: value alternating with tariff register no. and criteria</td>
</tr>
<tr>
<td>

9) Pulse counter 1: pulse value alternating with reading[2)]</td>
<td>










10) Pulse counter 2: pulse value alternating with reading[2)]</td>
<td>

11) Pulse counter 3: pulse value alternating with reading[2)]</td>
<td></td>
</tr>
</table>



[1)] Up to the end of the month / the 15th of the month (for the semimonthly values) the consumption and date will be shown as 0.

[2)] Three pulse inputs are an option. They can be set using the software „Device Monitor“.



Level 2 / Technician's Loop:

 1) Current power in kW	 2) Current flow in m³/h. (When negative flow, value is displayed negative.)	 3) Inlet flow temperature in °C	 4) Outlet flow temperature in °C
 5) Temperature difference in K. (Cooling energy: Value is displayed negative.)	 6) Before start of operation: days since manufacture  After start of operation: days since manufacture alternating with days of operation after reaching an energy value > 10 kWh	 7) M-bus address	 8) Serial number
 9) Firmware version			



Level 3 / Statistics Loop:

		1) – 30) Semimonthly values: date alternating with heat energy, cooling energy, volume, value tariff register 1, value tariff register 2.[1)] (If the meter has 3 pulse inputs, their values follow.[2)])	

Level 4 / Maximum Values Loop:

 1) Maximum power alternating with date and time	 2) Maximum flow alternating with date and time	 3) Maximum inlet flow temperature alternating with date and time	 4) Maximum outlet flow temperature alternating with date and time
 5) Maximum temperature difference alternating with date and time			

Level 5 / Parametrizing Loop:

 1) Parametrizing „unit of energy“	 2) Parametrizing „installation point“		

8.1 Parametrizing loop

The following characteristics of the meters can be set on location, **only once,** by pushing the button or alternatively using the „Device Monitor“ software:

- **unit of energy** (kWh; MWh; GJ; MMBTU; Gcal)
- **installation point** (inlet flow; outlet flow).

These parametrizing options are only available when the amount of energy is still <= 10 kWh.
Make sure that these characteristics are set as needed before starting up the system.
Setup by pushing the button: In order to start the editing mode for parametrizing you must select the respective item in the parametrizing loop and then push the button once again for 2-3 seconds. As an aid, after 2 seconds the
„editing pen“ will be displayed bottom left in the LCD (see below picture). As soon as it appears you have to let go of the button. Then the current display will start blinking.



By pressing the push-button briefly you can switch to the next option. By pressing the push-button longer the currently displayed option will be set. If no option is chosen there will be no change and as soon as the LCD goes out the edit mode will end automatically.

The following characteristic of those mechanical meter types designed to be used with glycol can be set on location **at any time** using the „Device Monitor“ software:

- **type and concentration of glycol in the medium** (propylene glycol; ethylene glycol; 20 %; 30 %; 40 %; 50%).

8.2 Detection of flow

As long as the meter detects some flow the following pictogram will be displayed bottom right in the LCD.

	flow detected

9. Application Conditions

AMTRON® S3 / AMTRON® S3+ / AMTRON® S3U		
Maximum flow qs/qp		2:1
Mechanical class		M2
Electromagnetic class		E2
Environmental class		C
Protection class flow sensor		IP65
Nominal pressure PN	bar	16
Mounting position		any, if there is no indication on type label
Flow sensor of AMTRON® S3 / AMTRON® S3+		
Temperature range medium heat	°C	15 – 90
Temperature range medium cooling	°C	5 – 50 (qp 1,5 and qp 2,5)
Flow sensor of AMTRON® S3U		
Temperature range medium heat	°C	15 – 90 15 – 130 high temperature (150; for maximal 2000 h) (optional)
Temperature range medium cooling	°C	5 – 50 (from qp 1,5 to qp 10)
Temperature range medium heat/cooling	°C	15 – 90 heat 15 – 120 high temperature (optional) 5 – 50 cooling
Calculator		
Ambient temperature in the field	°C	5 – 55 at 95 % relative humidity
Transport temperature	°C	-25 – 70 (for maximal 168 h)
Storage temperature	°C	-25 – 55
Protection class		IP65

10. Interfaces and Options

10.1 Optical (infrared) interface


For communication with the optical interface an optocoupler and the “Device Monitor” software are necessary. The optocoupler and “Device Monitor” are available as accessory equipment.
The optical infrared interface will be activated by automatically sending a header (according to EN 13757-3). Baud rate: 2400 baud.

Then you can communicate with the meter for 4 seconds. After every valid communication the meter is open for another 4 seconds. Afterwards the display is deactivated.
The number of read-outs per day via the optical interface is limited. During daily read-out at least 4


communications are possible. If read-outs are carried out more rarely, the possible number of communications will increase.

10.2 Retrofitting with an additional communication interface (optional)

We also offer a retrofittable meter to which communication interfaces can be added later. You will find the description of our optional interfaces in the operating instructions „Communication Interfaces S3(C)".
To retrofit such a meter with an additional communication interface the calculator´s adhesive seal has to be destroyed and the device´s calculator to be opened. **When the calculator is open, please observe the ESD requirements according to EN 61340-5-1.**
Use a screwdriver with a wide tip (4 - 5 mm) and carefully press in the two round predetermined breaking points above the cable feedthroughs (see picture 1).



Then insert the screwdriver into one of the two openings at an angle of approx. 45° and carefully lift the handle up to approx. 90° (see picture 2). The upper housing piece of the calculator is then no longer latched on this side.
Repeat this with the other opening. Now the upper housing piece can be taken off.



Plug the interface module on the right side of the PC board. The cables are to be fed through the rightmost cable feedthroughs into the calculator after removing the blind grommets. Close the calculator.

Protect the calculator against unauthorized opening using one of the numbered adhesive seals enclosed to the modules (stick it upon the seal destroyed). The added bar code label can be used for the purpose of documentation.


10.3 Exchanging the Battery

The meter's battery is easy to exchange by authorized technical personnel (our replacements only). Replaced batteries must be disposed of according to relevant environmental regulations.
To exchange the battery, open the meter´s calculator as described above in 10.2. Afterwards protect the calculator against unauthorized opening using one of the numbered adhesive seals enclosed to the batteries (stick it upon the seal destroyed). The added bar code label can be used for the purpose of documentation.



10.4 Mounting a power pack

If an external power supply is needed, only the power pack designed for our heat meter may be used. To connect the power pack, first open the meter´s calculator as described above in 10.2. Then remove the battery from the calculator and plug it into the battery connector in the power pack. Protect the power pack against unauthorized opening using one of the numbered adhesive seals enclosed. The added bar code label can be used for the purpose of documentation. (The battery is a backup in case of a power outage.)
The power pack cable (A) has two connectors; plug the one connector onto the contact fingers on the left-hand side of the PC board. Then feed the cable through the meter´s leftmost cable feedthrough (viewed from the front) after removing the blind grommet. The other connector is to be plugged into the female connector on the PC board.



Only authorized technical personnel may connect the power pack to the 230 V mains supply and check it. When the meter detects external power supply the pictogram of a mains plug appears in the display lower left. Close the calculator.
Protect the calculator against unauthorized opening using one of the numbered adhesive seals enclosed to the power pack (stick it upon the seal destroyed). The added bar code label can be used for the purpose of documentation.



11. Information Messages

When the instrument has detected an information message, the message symbol is displayed: ⚠
The specific message can be found at menu item 6 'Information message' in level 1 / main loop (se section 8, Display). The message code is displayed alternately in binary and hexadecimal form.
The instrument recognizes eight message causes, which can also occur in combination with each other.

Hexadecimal display	Description	Binary display
H 80	Low battery	1 at first place
H 40	Instrument has been reset	1 at second place
H 20	Electronics defective	1 at third place
H 10	Error in flow measurement system	1 at fourth place
H 08	Temperature sensor 2 short circuit	1 at fifth place
H 04	Temperature sensor 2 cable break	1 at sixth place
H 02	Temperature sensor 1 short circuit	1 at seventh place
H 01	Temperature sensor 1 cable break	1 at eighth place

„Temperature sensor 1" is the right temperature sensor (viewed from the front).

Example: Temperature sensor 1 cable break

Message	Low battery	Reset	Electronics defective	Error in flow measurement	Temperature sensor 2 short circuit	Temperature sensor 2 cable break	Temperature sensor 1 short circuit	Temperature sensor 1 cable break	Alternating hexadecimal message displayed (LCD)
Bit	7	6	5	4	3	2	1	0	
Display location	1	2	3	4	5	6	7	8	
Alternating binary message displayed (LCD)									

When a message ⚠ appears in the standard display (total heat energy), with the exception of the messages

- **Low battery (H 80)**
- **Reset (H 40)**
- **Error in flow measurement system (H 10; in the case of air in the ultrasonic measuring tube), the instrument must be exchanged and sent to the supplier for examination.**

11.1 Message description

Display	Message	Effect	Possible cause
H 80	Low battery	No influence on the calculation	Adverse environmental conditions; long operating time
H 40	Reset	No influence on the calculation	EMC, electromagnetic interference
H 20	Electronics defective	No energy calculations are carried out. The register for energy is not being updated (no new data is being stored).	Defective component, defect on the calculator PC board
H 10	Error in flow measurement system	No calculations are carried out. The registers for volume and energy are not being updated (no new data is being stored).	Connecting cable between the calculator housing and flow sensor damaged Ultrasonic flow sensor: Air in the system; contaminated flow sensor Mechanical flow sensor: Scanning is not functioning properly
H 08	Temperature sensor 2 short circuit	No energy calculations. The register for energy is not being updated (no new data is being stored).	Sensor cable damaged
H 04	Temperature sensor 2 cable break	No energy calculations. The register for energy is not being updated (no new data is being stored).	Sensor cable damaged
H 02	Temperature sensor 1 short circuit	No energy calculations. The register for energy is not being updated (no new data is being stored).	Sensor cable damaged
H 01	Temperature sensor 1 cable break	No energy calculations. The register for energy is not being updated (no new data is being stored).	Sensor cable damaged

12. Manufacturer & contacts

Engelmann Sensor GmbH
Rudolf-Diesel-Str. 24-28
69168 Wiesloch-Baiertal Germany

info@integra-metering.com
www.integra-metering.com


13. Operating Instructions Communication Interfaces S3(C)

13.1 Interfaces and Options

13.1.1 Optical (infrared) interface

For communication with the optical interface an optocoupler and the "Device Monitor" software are necessary. The optocoupler and "Device Monitor" are available as accessory equipment.
The optical infrared interface will be activated by automatically sending a header (according to EN 13757-3). Baud rate: 2400 baud.
Then you can communicate with the meter for 4 seconds. After every valid communication the meter is open for another 4 seconds. Afterwards the display is deactivated.
The number of read-outs per day via the optical interface is limited. During daily read-out at least 4 communications are possible. If read-outs are carried out more rarely, the possible number of communications will increase.

13.2. M-Bus (optional)



The M-Bus is a galvanically isolated interface for the transmission of meter data (absolute values).

General information about the M-Bus interface:
It is important to note that the acknowledged state of the art technology rules and the relevant legal restraints (international and local; see "Relevant Norms / Standards / Literature M-Bus") are to be observed.
The installation has to be performed by authorized, skilled persons.
If the regulations and the information in the installation and operating instruction manuals are not strictly followed, or if the installation is shown to be faulty, any resulting expenses will be charged to the company responsible for the installation.

Recommended type of cable: Telephone cable J-Y(ST)Y 2x2x0.8mm².
It is important to make sure that the topology of the M-Bus network (cable lengths and cross-sections) is suitable for the **baud rate (2400 Bd)** of the end instruments.

13.2.1. Relevant norms / standards / literature M-Bus

IEC 60364-4-41 (2005-12)	Low-voltage electrical installations - Part 4-41: Protection for safety - Protection against electric shock
IEC 60364-4-44 (2007-08)	Low-voltage electrical installations - Part 4-44: Protection for safety - Protection against voltage disturbances and electromagnetic disturbances
IEC 60364-5-51 (2005-04)	Electrical installations of buildings - Part 5-51: Selection and erection of electrical equipment - Common rules
IEC 60364-5-54 (2011-03)	Low-voltage electrical installations - Part 5-54: Selection and erection of electrical equipment - Earthing arrangements and protective conductors
EN 50310 (2011)	Application of equipotential bonding and earthing in buildings with information technology equipment
EN 13757-1_2015, -2_2004, -3_2013	Communication systems for meters and remote reading of meters
The M-Bus	A Documentation, Version 4.8, M-Bus User group

13.2.2 Additional technical specifications

The installation has to fulfill the requirements of the relevant norms / standards / literature (see paragraph 2.1) and the specifications as follows:

Maximum voltage M-Bus	42 V
Minimum voltage M-Bus	24 V
Maximum ripple voltage	200 mV; EN 13757-2_2004; 4.3.3.6
Maximum voltage potential differences	2 V

13.2.3 Technical data M-Bus

Primary address	0 (factory setting); 1 - 250 (configurable)
Baud rate	2400; 300
Connecting cable length	1 m
Number of possible read-outs	unlimited
Refresh of data	120 s; using a power pack: 2 s

13.3 Modbus RTU (optional)

The Modbus RTU Module is a galvanically isolated interface for the transmission of meter data (absolute values). It is designed for use with S3 heat meter and S3C calculator to connect them to Modbus RTU network using EIA-485 channel.

13.3.1 Technical data Modbus

Connector A	PowerSupply 12 V – 24V DC ± 10% (SELV power supply only)
Connector B	Modbus Network
Maximum power consumption	500 mW
Communication protocol	Modbus RTU
Channel	EIA-485 (galvanically isolated)
Baud rate	1200, 2400, 4800, 9600, 14400, 19200, 38400, 56000, 57600, 115200

13.3.2 Default factory settings

Communication parameters	9600 bps, 8N1 data format (8 data bits, none parity, 1 stop bit)
Update Rate Data from Meter	600 s
Modbus Slave ID*	1
Automatic Slave ID**	0 (deactivated)

* Acceptable values: 1 ... 247.

** If the automatic Slave ID is activated (set to = 1), the M-Bus address which is set in the meter is used for communication.

13.4. Wireless Interfaces

INTEGRA Metering offers the following radio interfaces:

- wireless M-Bus interface EN 13757-3, -4 (see chapter 13.4.1)
- LoRaWAN communication interface (see chapter 13.4.2)

General information about the radio interface:

Installation of radio components between or behind heating pipes, or the presence of other bulky metallic obstacles directly over or in front of the housing must be avoided.

The transmission quality (range, telegram processing) of radio components can be negatively influenced by instruments or equipment with electromagnetic emissions, such as telephones


(particularly LTE mobile radio standard), wi-fi routers, baby monitors, remote control units, electric motors, etc.
In addition, the construction of the building has a strong influence on the transmission range and coverage. Furthermore, when using installation boxes (substations) they must be equipped with non-metallic covers or doors.

The factory-setting of the clock in the meter is standard (winter) Central European Time (GMT +1). There is no automatic changeover to daylight savings (summer) time.

The radio function is deactivated upon delivery (factory-setting). See chapter 13.4.1 regarding the **activation of the radio interface.**

13.4.1. Radio interface wireless M-Bus EN 13757-3, -4 (optional)

The radio interface transmits meter data (absolute values).



Technical data radio

Frequency	868 MHz
Transmission power	up to 12 dBm
Protocol	wireless M-Bus based on EN 13757-3, -4
Selectable modes	S1 / T1 (Frame Format A) C1 (Frame Format B)
Telegrams	- short telegram in conformity to AMR (OMS-Spec_Vol2_Primary_v301 and _v402): energy (heat/cooling energy, pulse input 1 to pulse input 3), total volume, flow, power, information message, outlet flow temperature, temperature difference - long telegram for walk-by read-out: energy (heat/cooling energy, pulse input 1 to pulse input 3), total volume, information message, 15 monthly or 30 semimonthly values (compact mode)
Encryption	AES: Advanced Encryption Standard; key length: 128 bits

Radio configuration

Parameter	**Possible settings**
Mode	S1 / T1 / C1; unidirectional
Transmission period	00:00 - 24:00; any time period in the day
Transmission interval	10 seconds - 240 minutes
Weekdays	Monday – Sunday (any weekday)
Weeks in a month	1 – 4 (4: uninterrupted, incl. a possible 5th week)
Months	1 - 12
Radio activation date	01.01. - 31.12. (day. month)

AES-128-Encryption	- not encrypted;
	- encrypted according to MODE 5 or MODE 7:
	  - Master Key
	  - key per instrument


Type of telegram	- short telegram in conformity to AMR (OMS-Spec_Vol2_Primary_v301 and _v402) - long telegram for walk-by read-out

Activation of the radio interface
The radio interface **leaves the factory deactivated**. It can be activated as follows:

a) The radio function can be activated by pressing the push-button. Press the push-button until you change to the display loop "6" (module loop). Then change with a brief keystroke to the 2nd item "rAd(io) oFF" (see picture).



In order to start the editing mode you afterwards must press the push-button once again for 2-3 seconds. As an aid, after 2 seconds the "editing pen" will be displayed bottom left in the LCD. As soon as it appears you must let go of the button. Now the display shows "rAd(io) on" and in all display loops a black triangle (see picture).



b) The radio function can also be activated using the software "Device Monitor". This software can be ordered separately as an option.

The radio function can only be deactivated using the software "Device Monitor".

After activation of the radio function or modification of the radio parameters the meter remains in installation mode for 60 minutes. During this time, he sends telegrams in a 36-seconds-interval.

If using the **compact mode**, after activation the meter transmits during installation mode format telegrams and compact telegrams alternately.
During installation mode at least one meter of the version being installed (inlet or outlet flow, heat or heat/cooling, pulse inputs, display units) must be read out with the INTEGRA Metering "Read-out Software walk-by". The format of the telegram will be stored locally in the PC in an .xml file.
After completion of the installation mode only compact telegrams will be transmitted.

Later activation of the radio encryption
The AES encryption can also be activated later. It can be activated as follows:
a) The encryption can be activated by pressing the push-button. Press the push-button until you change to the display loop "6" (module loop). Then change with a brief keystroke to the 3rd item "AES oFF" (see picture).




In order to start the editing mode you afterwards must press the push-button once again for 2-3 seconds. As an aid, after 2 seconds the "editing pen" will be displayed bottom left in the LCD. As soon as it appears you have to let go of the button. Now the display shows "AES on" (see picture).



b) The encryption can also be activated using the software "Device Monitor". This software can be ordered separately as an option.
The encryption can only be deactivated using the software "Device Monitor".

13.4.2 LoRaWAN interface

The LoRaWAN interface transmits meter data (absolute values).



Technical data Radio characteristics

Frequency	868 MHz
Output power	14 dBm
Receiver sensitivity	-135 dBm

LoRaWAN characteristics

Device class	Class A, Bi-directional
LoRa version	1.0.2 Rev B
Activation	OTAA* or ABP*
Data rate	DR0-DR5 (250 bit/s-5470 bit/s)

*OTAA = Over-the-air activation.
** ABP = Activation by personalization.

LoRa module configuration

The module can be configurated by using the Device Monitors or the OTC App.

Parameter	Possible settings	Factory setting
Power mode	Active Inactive	Inactive
Configuration Lock	Open Locked	Open
Synchronize meter time	on off	off
Activation type	OTAA ABP	OTAA
EcoMode	off 6 years 10 years	EcoMode 10 years
Transmit interval *[Min.]	5 ... 1440	60
Message format**	Standard INTEGRA Metering Compact JSON Scheduled - daily redundant Scheduled - extended Combined heat/cooling	Standard
Pulse input selection	Choice between 0-3 pulse inputs	0

* The actual transmission interval depends on the type of telegram and the current data rate. The transmission interval is adjusted accordingly in order to guarantee the set battery life (Eco Mode 10 or 6 years). You can find more information in the „Manual LoRa Module“.
** For pulse input option, the telegram type „INTEGRA Metering“ must be selected.


Activation of the radio interface

The radio interface is deactivated by default and can be activated in one of the three following ways:


a) **NTC interface - via Elvaco OTC App**; further information is available in the operating instructions of the Elvaco OTC App: https://www.elvaco.se/Image/GetDocument/en/269/elvaco-otc-app-manual-english.pdf

b) **Optical interface - via the INTEGRA Metering configuration software Device Monitor** – from version 2.22; further information is available in the operating instructions of the Device Monitor. The software can be ordered separately.

c) **Via the heat meter menu;**
Press and hold the button to switch to display loop "6" (= module loop; see Chapter 3 Display in the Module Loop (Optional)). Then switch to the second loop with a short press of the button – 6-02 – „EnA oFF“ (see image).




In order to start the edit mode, you must then press the key press once more for 2-3 seconds. As an aid, an “editing pen” symbol appears in the lower left corner of the LCD after 2 seconds. As soon as it can be seen, you must release the button. The display now shows „EnA on“ and a black triangle in all display loops (see image).




Connection to the LoRaWAN Network

To check whether the meter has already connected to the LoRaWAN network, change from loop 6-02 to loop 6-03 by briefly pressing the button. As long as the meter is searching for the LoRaWAN network, „LorA PEn“ appears in the LCD; the time between each connection attempt is gradually reduced to at least once a day.



As soon as the meter has connected to the LoRaWAN network, “LorA Con” appears in the LCD.



13.4.3 Three additional pulse inputs (optional; only in conjunction with M-Bus or radio)

With this option, additional instruments with pulse outputs can be read out via optical interface, M-Bus or radio.

General information about pulse inputs:

It is important to note that the acknowledged state of the art technology rules and the relevant legal restraints (international and local; see “Relevant Norms / Standards / Literature Pulse Inputs”) are to be observed.

The installation has to be performed by authorized, skilled people.

If the regulations and the information in the installation and operating instruction manuals are not strictly followed, or if the installation is shown to be faulty, any resulting expenses will be charged to the company responsible for the installation.

Relevant norms / standards / literature pulse inputs

IEC 60364-4-41 (2005-12)	Low-voltage electrical installations – Part 4-41: Protection for safety – Protection against electric shock
IEC 60364-4-44 (2007-08)	Low-voltage electrical installations – Part 4-44: Protection for safety – Protection against voltage disturbances and electromagnetic disturbances
IEC 60364-5-51 (2005-04)	Electrical installations of buildings – Part 5-51: Selection and erection of electrical equipment – Common rules
IEC 60364-5-54 (2011-03)	Low-voltage electrical installations – Part 5-54: Selection and erection of electrical equipment – Earthing arrangements and protective conductors
EN 50310 (2011)	Application of equipotential bonding and earthing in buildings with information technology equipment
EN 1434-2 (2016)	Heat Meters – Part 2: Constructional requirements

Technical data pulse inputs

Pulse input class	IB according to EN 1434-2:2016
Connecting cable length	1 m
Voltage supply	+ 3 V DC
Source current	= 1,5 µA
High level input threshold	U ≥ 2 V
Low level input threshold	U ≤ 0,5 V
Pull-up resistor	2 MΩ
Pulse length	≥ 100 ms
Pulse frequency	≤ 5 Hz

Possible combinations of the different input (class IB) and output (class OA) devices

	Class IA	Class IB	Class IC	Class ID	Class IE
Class OA	yes	yes	no	yes	no
Class OB	yes	no	no	yes	yes
Class OC	no	yes	yes	no	no
Class OD	no	no	yes	no	no
Class OE	no	no	no	no	yes

Setting up the three additional pulse inputs

The optional pulse inputs 1 + 2 + 3 for external meters can be set up using the "Device Monitor" configuration software. You can configure serial number, manufacturer, version (0 ... 255), medium code, input pulse value, unit and starting value of the external meters.

Set-up possibilities

Pulse value	Units
1	liters / kWh / pulse without unit
2,5	liters / kWh / pulse without unit
10	liters / kWh / pulse without unit
25	liters / kWh / pulse without unit
100	liters / kWh / pulse without unit
250	liters / kWh / pulse without unit
1000	liters / kWh / pulse without unit

Installation notes for pulse inputs:
It is important that the pulse cables not be affected by (or exposed to) an external voltage!
Check the polarity of pulse generators with "open collector" outputs.
The cable wires must not touch each other during installation, otherwise pulses will be counted in the instrument. When setting up the meter it may be necessary to adjust the meter reading of the instruments connected and the pulse value using the "Device Monitor" software.


For transmitting the values of the pulse inputs via radio, transmission must be set using the "Device Monitor" software, if the meters were not already ordered with the transmission of these values set.
Select the menu item „Parameterization of the module" in the software. Set the radio transmission in the menu item „Transmission of values for the pulse inputs". (The transmission of these values via M-Bus is always set in the factory setting.)

Pin assignments 6-wire cable

Color	Connection
Pink	IE1+
Grey	IE1⊥
Yellow	IE2+
Green	IE2⊥
Brown	IE3+
White	IE3⊥

13.4.4 One potential-free pulse output (optional)

Important note: This module can be used for the compact heat meter S3 from firmware version 1.03 on, for the calculator S3C from firmware version 1.00 on. The potential-free pulse output provides counting pulses of the meter.
The pulse output closes corresponding to the pulse value, see item „pulse value pulse output 1" in display loop "6" (module loop).



	Heat meter	Cooling meter	Heat/cooling meter
Possible settings pulse output 1	heat energy (factory setting) or volume	cooling energy (factory setting) or volume	heat energy (factory setting) or volume

From firmware version 1.03 (S3) and 1.00 (S3C) on the meter recognizes nominal size and unit of energy and autonomously sets the pulse values for energy and volume according to the following notes.

S3 – pulse output for energy:

	Display shows kWh / MWh	Display shows Gcal	Display shows GJ	Display shows MMBTU
q_p 0,6 m^3/h	1 kWh/pulse	1 Mcal/pulse	10 MJ/pulse	10 MMBTU/pulse
q_p 1,5 m^3/h	1 kWh/pulse	1 Mcal/pulse	10 MJ/pulse	10 MMBTU/pulse
q_p 2,5 m^3/h	1 kWh/pulse	1 Mcal/pulse	10 MJ/pulse	10 MMBTU/pulse
q_p 3,5 m^3/h	10 kWh/pulse	10 Mcal/pulse	10 MJ/pulse	10 MMBTU/pulse
q_p 6 m^3/h	10 kWh/pulse	10 Mcal/pulse	10 MJ/pulse	10 MMBTU/pulse
q_p 10 m^3/h	10 kWh/pulse	10 Mcal/pulse	10 MJ/pulse	10 MMBTU/pulse

S3 – pulse output for volume:
The pulse value for volume is always determined as follows: Display shows m^3 -> pulse value: 100 l/pulse (0,1 m^3/pulse).

S3C – pulse output for energy:
The pulse value for energy is always determined by **the second-to-last place** of the energy display.
Examples:
Display: 0 kWh -> pulse value: 10 kWh/pulse
Display: 0,000 MWh -> pulse value: 0,01 MWh/pulse
Display: 0,000 GJ -> pulse value: 0,01 GJ/pulse.

S3C – pulse output for volume:
The pulse value for volume is always determined by **the third-to-last place** of the volume display.
Examples:
Display: 0,000 m^3 -> pulse value: 100 l/pulse (0,1 m^3/pulse)
Display: 0 m^3 -> pulse value: 100 m^3/pulse.

Pin assignments 4-wire cable


Color	Connection
Yellow	IA1
Green	IA1
Brown / White	not reserved

Technical data for one pulse output and two pulse outputs

Pulse outputs class	OA (electronic switch) according to EN 1434-2:2016
Connecting cable length	1 m
Switching voltage, maximum	30 V
Switching current, maximum	27 mA
Contact resistance (on) max.	74 Ω
Contact resistance (off) min.	6 MΩ
Closure time	100 ms
Interval between pulses	100 ms

13.4.5 Two potential-free pulse outputs (optional)

The potential-free pulse outputs provide counting pulses of the meter. The pulse outputs close corresponding to the pulse value, see items „pulse value pulse output 1“ and „pulse value pulse output 2“ in display loop “6” (module loop).



	Heat meter	Cooling meter	Heat/cooling meter
Pulse output 1	heat energy	cooling energy	heat energy
Pulse output 2	volume	volume	cooling energy

Pulse outputs for energy:
The pulse value for energy is always determined by **the last place** of the energy display. Examples:
Display: 0 kWh -> pulse value: 1 kWh/pulse
Display: 0,000 MWh -> pulse value: 0,001 MWh/pulse
Display: 0,000 GJ -> pulse value: 0,001 GJ/pulse

Pulse outputs for volume:
The pulse value for volume is always determined by **the second-to-last place** of the volume display. Example:
Display: 0,000 m³ -> pulse value: 10 l/pulse (0,01 m³/pulse)

13.4.6 Pin assignments 4-wire cable

Color	Connection
Yellow	IA1
Green	IA1
Brown	IA2
White	IA2


13.5 Retrofitting with an Additional Communication Interface

During installation of the retrofitting module observe the ESD requirements according to EN 61340-5-1.
This means that on location an antistatic wrist strap with an integrated 1 MΩ resistor has to be used which must be connected to a proper spot: This is either a grounded pipe or – only with an appropriate adapter! – a Schuko plug grounding socket. The antistatic wrist strap must be worn tightly on the skin of the wrist.


13.5.1 Retrofitting S3 with an additional communication interface (optional)

We also offer a retrofittable meter to which communication interfaces can be added later.


To retrofit such a meter with an additional communication interface the calculator´s adhesive seal has to be destroyed and the device´s calculator to be opened. Use a screwdriver with a wide tip (4 - 5 mm) and carefully press in the two round predetermined breaking points above the cable feedthroughs (see picture 1).




Then insert the screwdriver into one of the two openings at an angle of approx. 45° and carefully lift the handle up to approx. 90° (see picture 2). The upper housing piece of the calculator is then no longer latched on this side.
Repeat this with the other opening. Now the upper housing piece can be taken off.



Plug the interface module on the right side of the PC board (see picture 3). The cables are to be fed through the rightmost cable feedthroughs into the calculator after removing the blind grommets. Close the calculator.
Protect the calculator against unauthorized opening using one of the numbered adhesive seals enclosed to the modules (stick it upon the seal destroyed). The added bar code label can be used for the purpose of documentation.









To remove a module the upper housing piece must be carefully pressed against the rear panel of the lower housing piece during opening the calculator. Thus the two rear snap-fits of the upper housing piece lever out the module of the PC board (see picture 4).



13.6 Display in the Module Loop (Optional)

Level 6 / Module Loop:

		
	  Or:  	  Or:  
		
		
1) Display of plugged module (alternatively):	2) Display depending on plugged module and setup:	3) Display depending on plugged module and setup:
5 = 1 pulse output		
8 = wireless M-Bus + optional 3 pulse inputs	wireless M-Bus (radio) off/ wireless M-Bus (radio) on; LoRa on/ LoRa off	radio encryption (AES) off; radio encryption (AES) on; LoRa pending/ LoRa connected
9 = M-Bus + optional 3 pulse inputs; 9 = Modbus		
10 = 2 pulse outputs	pulse value / pulse output 1	pulse value / pulse output 2

14. EU Declaration of Conformity (DoC)

Scan the QR code below to view the EU Declaration of Conformity (DoC):